

# Detection of graphene in air

A proposal based on thermal properties

Authors:

Danieli Silva Domingues

Fernanda Vieira

Guilherme Lenz

Jefferson Patrício Nascimento

Clascídia Furtado

Alberto Avellar Barreto

Adelina Pinheiro Santos

Camila de Oliveira Viana

PARTNERSHIP:




# BRAZILIAN GRAPHITE


◆ 2° WORLD RESERVE

◆ 3° WORLD PRODUCER

TOTAL WORLD PRODUCTION= 270 millions ton



## GRAPHITE PRODUCTION [mil ton/year]



Data source: U.S. Geological Survey, Mineral Commodity Summaries, January (2018)

# PROJECT MGGRAFENO

FROM NATURAL GRAPHITE TO GRAPHENE



PILOT  
PRODUCTION  
PLANT



**+150 kg/year**  
INSTALLED CAPACITY




**+40 COLABORATORS**

**3 PRODUCTS**

GRAPHENE (1-5) GRAPHENE (6-10)



GRAPHITE  
NANOPLATELET



UFMG  
UNIVERSIDADE FEDERAL  
DE MINAS GERAIS



CODEMGE  
Companhia de Desenvolvimento de Minas Gerais

**\$5.3 MI**  
INVESTED

APPLICATIONS  
DEVELOPMENT



# EHS

ENVIROMENT, HEALTH AND SAFETY

100%



LIQUID WASTE TREATMENT

AIR 100%  
CONFORMITY



ZERO ACCIDENT

# EHS

ENVIROMENT, HEALTH AND SAFETY

100%



LIQUID WASTE TREATMENT

AIR 100%  
CONFORMITY



ZERO ACCIDENT

## AIR MONITORING (INDOOR AND OUTDOOR) IN ACCORDANCE WITH BRAZILIAN ENVIRONMENTAL LEGISLATION\*

\*CONAMA 03/1990



Hi-Vol samplers used in course of routine monitoring activities

camila.viana@cdtn.br





# OUR GRAPHENE (1-5)

FEW LAYER GRAPHENE

N: 1-5

COMBUSTION TEMP. = 620 °C

PURITY = ~98.5%





# DEVELOPMENT OF A METHOD TO DETECTED GRAPHENE DIRECT IN THE AIR COLLECTING FILTERS


Why TGA?

Allows quantification | Good for complex matrices | No special sample preparation needed

## METHODOLOGY

STANDARDIZED STUDY

DISPERSIONS AND  
FILTER PREPARATION



DEPOSITED VIA  
FILTRATION

1mg/mL; 0.1mg/mL; 0.01mg/mL

THERMOGRAVIMETRIC  
ANALYSIS




40 °C to 1000 °C



# RESULTS

## STANDARDIZED STUDY



Thermal analysis presented a decomposition range typical of few-layer graphene  
Control filters (0 mg/mL) thermally almost stable with weight loss of approximately 2%



## RESULTS

### STANDARDIZED STUDY

- The weight loss of filters loaded with different types of particulate matter (environmental/outdoor sampling) occurs until  $\sim 400^{\circ}\text{C}$
- The presence of graphene added a new decomposition event in the temperature range of  $400 - 750^{\circ}\text{C}$



# RESULTS

REAL SAMPLE TEST




FILTER PREPARATION  
precleaned (muffle furnace)

AIR SAMPLING  
(Hi-Vol)  
24h of exposure

THERMOGRAVIMETRIC  
ANALYSIS  
10°/min; synthetic air






Presence of a thermal decomposition event in the same temperature range of graphene




# RESULTS

REAL SAMPLE TEST




## Filter's Scanning Electron Microscopy with Energy Dispersive Spectroscopy





# RESULTS

REAL SAMPLE TEST

Filter's X-Ray Diffraction



Filter's Raman Spectroscopy



HV	Mag	Sig	WD	Spot	HFW	Tilt	10.0µm
10.0 kV	5000x	SE	10.1 mm	4.0	27.04 µm	-0.0 °	CENTRO DE MICROSCOPIA UFMG

# CONCLUSIONS

- ✓ The thermogravimetric analysis can be used to **detect** small amounts of graphene deposited on the filters
- ✓ It was also possible to **detect** graphene in real samples, after indoor particulate matter sampling at the MGgrafeno pilot production plant

## NEXT STEPS

Is possible to estimate or quantify, and to differentiate graphene/graphite exposition by using TGA analysis?

THANK YOU!

**UFMG**  
UNIVERSIDADE FEDERAL  
DE MINAS GERAIS

**CDTN**  
CENTRO DE DESENVOLVIMENTO  
DA TECNOLOGIA NUCLEAR

**CODEMGE**  
Companhia de Desenvolvimento de Minas Gerais

